

POCKET HOLE SCREW GUIDE

Material Thickness	1/2"		5/8"	3/4"	7/8"	1"	1 1/8"	1 1/4"	1 3/8"	1 1/2"	2" or larger
Screw Length	3/4"	1"	1"	1 1/4"	1 1/2"	1 1/2"	1 1/2"	2"	2"	2 1/2"	2 1/2" HD
Head	Pan-Head	Pan-Head	Pan-Head	Maxi-Loc	Maxi-Loc	Maxi-Loc	Maxi-Loc	Maxi-Loc	Maxi-Loc	Maxi-Loc	Maxi-Loc
Notes	When using a Micro Jig	When using a Reg Jig									Use an HD Jig

course thread - MDF, particle board, plywood, melamine and soft woods
 fine thread - hard woods